



IP-HMTD Hitch Mount Tube Dispenser



PART #	CODE "I" LIST	DESCRIPTION
<u>Hitch Mount Tube Dispenser</u>		
IP HMTD	\$750.00	Hitch Mount Tube Dispenser



The Hitch Mount Tube Dispenser (HMTD) has been designed to help install Irripod tubing faster and easier, but will also work with drip tubing and other types of coiled products. It is fully adjustable, easy to take apart for transport and storage, and plated for long service life.

HMTD in use:



Irripod installed and operating:





IP-HMTD Hitch Mount Tube Dispenser assembly instructions


Step 1: Insert the 2" square tube into the hitch and using the supplied pin install the base on the other end.



Step 2: Install the rubber friction disc and the hub onto the base. The rubber disc acts as a friction brake.



Step 3: Install the four spokes into the hub and slide on four vertical spokes with the thumb screws on the inside.



Step 4: Adjust the vertical spokes position and put on your coil of tubing. Tighten down the thumb screws.



Step 5: Install four horizontal spokes onto the vertical spokes. These keep the tubing from flipping up while dispensing.



Step 6: Cut the tape on the tubing and dispense. Two methods can be used:
1) Attach the tubing to an ATV or tractor and pull away slowly (3mph max) with the HMTD staying stationary.
2) Attach the tubing to something stationary and slowly pull the truck and HMTD away (3mph max).

Be careful and dispense the tube slowly or damage and/or injury may result. Do not stand near the dispenser when in use. Do not transport the dispenser while assembled in the hitch.